



MASSEY FERGUSON 35/135 TRACTOR WIRING DIAGRAM




www.qtponline.com


Email
info@qtponline.com

Telephone
00 353 44 934 1638


MASSEY FERGUSON 35 WIRING DIAGRAM DIESEL 3 CYLINDER WITH DYNAMO (GENERATOR)



MASSEY FERGUSON 35 WIRING DIAGRAM DIESEL 3 CYLINDER WITH ALTERNATOR



MASSEY FERGUSON 35 WIRING DIAGRAM LIGHTS & HOOTER CIRCUITS



Electrical Connections are as follows :

The terminals are labelled with DIN72552 numbers

30 = Power in (From ignition switch accessory terminal no.2)

49 = Power to hooter (Horn)

57 / 58 = Power to park lights, dashboard panel & no plate lights

56A = Headlights high beam

56B = Headlights low beam

MASSEY FERGUSON 135 INDICATORS

